






Wiring diagram Yamaha DTR125

PV servo DTR125



PPV-RZ2



to HT coil low tension side

- | | |
|--------------------|------------|
| B/R - black/red | V - violet |
| B/Y - black/yellow | Y - yellow |
| W/R - white/red | W - white |
| W/B - white/black | BI - blue |
| Y/BI - yellow/blue | O - orange |
| Y/G - yellow/green | R - red |
| G/B - green black | B - black |
| | Br - brown |